






Welcome Guide

www.sohnne.com

ASSEMBLY

Place the column onto the base, then place the chair shell onto the column.



Tilt lock handle: The chair has two seating positions, locked and tilting. Pull the tilt lock handle outward when you want the chair to tilt. Push the tilt lock handle inward to lock the chair to an upright firm position. Do not adjust the tilt lock handle if the chair is currently occupied.

Notes:

- The mechanism is tightened in the factory for safety, and may be stiff at first. Over time, it will soften.
- The column does not allow height adjustment.



